

ALPENHEAT

user manual

Heated **FIRE CUSHION**

Model: AJ7-APP



the heat is on.
www.alpenheat.com



(EN) Responsible person for
General Product Safety Regulation (GPSR): Tanja Gragl

(DE) Zuständige Person für
Produktsicherheitsverordnung (GPSR): Tanja Gragl

(BG) Отговорно лице за Регламента за обща безопасност
на продуктите (GPSR): Tanja Gragl

(DK) Ansvarlig for General Product Safety
Regulation (GPSR): Tanja Gragl

(CZ) Odpovědná osoba za Všeobecné nařízení o
bezpečnosti výrobků (GPSR): Tanja Gragl

(EE) Üldise tooteohutuse määruse (GPSR) eest
vastutav isik: Tanja Gragl

(ES) Responsable del Reglamento General de Seguridad
de Productos (GPSR): Tanja Gragl

(FI) Vastuushenkilö Yleinen
tuoteturvallisuusmääräys (GPSR): Tanja Gragl

(FR) Responsable du Règlement Général sur
la Sécurité des Produits (GPSR) : Tanja Gragl

(GR) Υπεύθυνη για τον Γενικό Κανονισμό Ασφάλειας
Προϊόντων (GPSR): Tanja Gragl

(HR) Odgovorna osoba za Uredba o općoj sigurnosti
proizvoda (GPSR): Tanja Gragl

(HU) Az Általános Termékbiztonsági
Szabályzatért (GPSR) felelős személy: Tanja Gragl

(IT) Persona responsabile per Regolamento generale
sulla sicurezza dei prodotti (GPSR): Tanja Gragl

(LT) Už Bendrąjį gaminių saugos reglamentą (GPSR)
atsakingas asmuo: Tanja Gragl



[LV] Atbildīgā persona par Vispārējā produktu drošības regula (GPSR): Tanja Gragl

[NL] Verantwoordelijke persoon voor Algemene productveiligheidsverordening (GPSR): Tanja Gragl

[NO] Ansvarlig for General Product Safety Regulation (GPSR): Tanja Gragl

[PL] Osoba odpowiedzialna za Ogólne rozporządzenie dotyczące bezpieczeństwa produktów (GPSR): Tanja Gragl

[PT] Responsável pelo Regulamento Geral de Segurança de Produtos (GPSR): Tanja Gragl

[RO] Persoană responsabilă pentru Regulamentul general privind siguranța produselor (GPSR): Tanja Gragl

[RS] Одговорно лице за Општу уредбу о безбедности производа (ГПСР): Тања Грагл

[RU] Ответственное лицо за Общие правила безопасности продукции (GPSR): Таня Грагл.

[SE] Ansvarig person för General Product Safety Regulation (GPSR): Tanja Gragl

[SI] Odgovorna oseba za Predpisi o splošni varnosti proizvodov (GPSR): Tanja Gragl

[SK] Zodpovedná osoba za Všeobecné nariadenie o bezpečnosti výrobkov (GPSR): Tanja Gragl

Alpenheat Produktions- u. Handels GmbH

Kirchweg 1/3

8071 Hausmannstätten, AUSTRIA

www.alpenheat.com

Tel: +43 3135 82396

Email: office.eu@alpenheat.com




INSTRUCTIONS:


Charge the battery with the included battery charger.




Plug the connector to the battery and choose a temperatur level on the battery or with our APP



Feel the soothing warmth within minutes!



Unplug the connector from the battery. Remove the battery for storage.



BATTERY:

Colour of lights:



red:
BOOST



orange:
HIGH



green:
MEDIUM



blue:
LOW

Amount of lights:



4 of 4 lights:
100% charged



3 of 4 lights:
75% loaded





2 of 4 lights:
50% loaded



1 of 4 lights:
25% loaded



0 of 4 lights:
flat



OPERABLE
WITH
APP



Manual control
of the heating
levels with button



The full EU Declaration of Conformity is available at/*Die vollständige EU-Konformitätserklärung ist unter folgender Adresse verfügbar:*
<https://alpenheat.com/instruction/compliance/AJ7-APP.pdf>



 HEATING AREA



ALPENHEAT Produktions- & Handels GmbH
Kirchweg 1/3, 8071 Hausmannstätten, Austria, Europe
T: +43 3135 82396 _ **M:** office.eu@alpenheat.com

www.alpenheat.com

				EN.....	8
				DE.....	13
<hr/>					
				BG	18
				CZ.....	23
				DK.....	28
				EE.....	33
				ES.....	38
				FI.....	43
				FR.....	48
				GR.....	53
				HR.....	58
				HU.....	63
				IT.....	68
				LT.....	73
				LV.....	78
				NL.....	83
				NO.....	88
				PL.....	93
				PT.....	98
				RO.....	103
				RS.....	108
				RU.....	113
				SE.....	118
				SI.....	123
				SK.....	128

AVAILABLE
SOON



DE

BG

CZ

DK

EE

ES

FI

FR

GR

HR

HU

IT

LT

LV

NL

NO

PL

PT

RO

RS

RU

SE

SI

SK

ALPENHEAT Heated cushion with APP



Model:
AJ7-APP FIRE CUSHION

AT A GLANCE:

- 1 cushion with integrated heating element (AJ7-APP)
- 1 Battery pack (BP3c)
- 1 USB-C Adapter (LG34c) and USB-C charging cable (LG35c)

SAFETY INSTRUCTIONS

Keep the product out of the reach of small children, as it contains small parts which could be swallowed. This product should not be used by individuals unable to determine when the temperature is too hot or too cold. Small children are more sensitive to hot and cold. Certain illnesses, e.g. diabetes, can cause impaired temperature sensitivity. Persons with disabilities or infirm persons might not be able to communicate that they are too warm or too cold. Therefore, the product is not suitable for children under the age of three, the infirm or individuals insensitive to heat. If in doubt or if you have cardiovascular problems consult your doctor before using the product. Only use the original recharger supplied with the product for charging the batteries. It has been designed for indoor use only and should not be exposed to moisture. Do not insert metal or other objects into the connection sockets or plug as this can damage the product. If you notice that the connection cables or any other parts are damaged, do not use the product. Do not make any modifications to the product and do not use it for any purpose other than intended. If you feel any unpleasant sensation, such as tingling, that may be a sign that the heat setting is set too high and should be reduced immediately or disconnect the cushion from the battery pack. If the product is not in use, the battery packs have to be disconnected from the cushion. Alpenheat products are not compatible with one another or with products from other manufacturers, so never use chargers, heaters or battery packs from other products.

HOW TO CHARGE THE BATTERIES AND HOW TO GET STARTED

1. Fully charge the battery before using the product. Plug the battery into the charger. The green LEDs on the battery flash, indicating that the battery is charging. Charging status: see the diagram *Battery Status. When the battery is fully charged, the green LEDs on the battery stop flashing and stay on.
2. Insert the plug of the cushion into the battery. One red LED will start to flash. The battery only works when it is plugged into the cushion.

GETTING STARTED WITH THE APP:

3. Download the free APP.
4. Activate Bluetooth on your phone, then open the APP.
5. In the APP: select cushion in the main product overview.
6. In the APP: click on the flashing blue Bluetooth connection icon on the cushion.

- Now the cushion is connected with your APP.
- To change the temperature either click the heat level button in the APP or press the switch on the battery.
- Click the on/off button in the APP to change to stand-by mode. The red LED on the battery flashes.

To change the heat setting (APP):

- Press the "LOW" button (blue) in the APP. The LEDs on the batteries are blue and the cushion is working in low mode.
- Press the "MEDIUM" button (green) in the APP. The LEDs on the batteries are green and the cushion is working in medium mode.
- Press the "HIGH" button (yellow) in the APP. The LEDs on the batteries are yellow and the cushion is working in high mode.
- Press the "BOOST" button (red) in the APP. The LEDs on the batteries are red and the cushion is working in boost mode.

 To turn on or off press the button: GREEN = ON, YELLOW = OFF

MANUAL OPERATION:

Plug the cushion into the battery, the red LED flashes. Press and hold the on/off button on the battery until the green LEDs light up. The battery is on and working in medium mode.

To change the heat setting (manual operation):

- Press the on/off switch again, the battery LEDs are yellow, and the cushion is working in HIGH mode.
- Press the on/off switch again, the battery LEDs are red, and the cushion is working in BOOST mode.
- Press the on/off switch again, the battery LEDs are blue, and the cushion is working in LOW mode.
- Press the on/off switch again, the battery LEDs are green, and the cushion is working in MEDIUM mode.
- Press and hold the on/off switch on the battery until the LEDs go out. The red LED flashes and the battery will stop output, and the cushion will not heat-up. The battery is in stand-by mode.
- To turn the battery off completely, unplug the cable of the cushion from the battery.

BATTERY LEVEL INDICATOR: *Battery status

When the battery is not connected to the cushion, press the on/off switch on the battery until the LEDs light-up. The LEDs show how fully charged the battery is (*see column right).

When the battery is connected to the cushion, depending on the heat setting, the glowing red/orange/green/blue LEDs show you how fully charged the battery is.

*Battery status:

	4 of 4 lights: 100% charged
	3 of 4 lights: 75% loaded
	2 of 4 lights: 50% loaded
	1 of 4 lights: 25% loaded
	0 of 4 lights: flat

ELECTRICAL PARAMETERS:

Li-Ion battery pack: Battery voltage: 7.4V

Cushion battery capacity: 2200mAh/16.28 Wh

CHARGER PARAMETERS:

Input: AC/100-240V 50-60Hz Output: 5V/2.4A

Heating duration 2–10 hours depending on the setting selected.

The battery pack is water repellent and shockproof. Under no circumstances should you take this apart.

USE:

The heated cushion provides comfortable and continuous warmth. Do not allow your body to get cold in the first place, because more energy will be required to warm it up, than if you had turned the heat on right at the beginning.

MAINTENANCE RULES FOR LI-ION AND LI-PO BATTERIES:

- The first charging process is very important! Please charge the battery completely before the first use.
- If a battery is discharged below its nominal voltage, this might trigger further processes, which could damage or destroy the battery.
- Therefore, ALPENHEAT batteries have built-in electronics that switch off the device before such a deep discharge happens.
- Frequent overcharging can permanently damage the battery. That's why the charger stops the charging process automatically as soon as the battery is fully charged. Repeatedly reconnecting a charged battery to the power supply will not increase the charging level!
- Charging should normally only be carried out at room temperature (about 18°C - 21°C). Avoid charging a cold battery, as this might damage the cells. Allow the battery to warm up at room temperature in order to charge it under ideal conditions.
- High temperatures might also damage the battery. Never leave the battery in the sun or in the car on hot and sunny days.
- Li-Ion batteries and Li-Polymer batteries should ideally be stored at room temperature.
- Fully charged or empty Li-ion batteries should not be stored for a longer period of time. In complex tests, the optimum storage condition was determined at a capacity of 30% to 50% and at a low temperature, but not below 0°C.
- Storage at -5°C to 45°C (Li-Ion) and at 0°C to 40°C (Li-Polymer) is possible, but not recommended
- Batteries have to be charged every 6 months.
- Even if not in use batteries lose energy. A Li-Ion battery loses about 3% to 5% per month.
- Always dispose of used and old batteries in an environmentally correct way.

CLEANING:

- Remove battery pack
- Do not machine or hand wash.
- Spot cleaning with mild soap is recommended, using a damp cloth or soft brush.
- Just wipe, do not immerse the whole thing in the water.
- Do not use bleach or strong detergent.
- Make sure the cushion is dry before storing it.
- Do not tumble dry / do not wring
- Do not iron

DISPOSAL OF PRODUCT

This product must be disposed of according to the prevailing guidelines for disposing of used electrical and electronic appliances. The symbol on the product or on its packaging indicates that this product must not be treated as household waste, but must be disposed of at a collection point for the recycling of electrical and electronic appliances. The product contains a lithium-ion (Li-ion) battery pack. The battery pack must not be taken apart, thrown into a fire or short-circuited. The battery pack must be disposed of properly. Appropriate containers for battery disposal are available in shops that sell batteries, as well as at municipal waste collection places. By your contribution to the correct disposal of this product you are helping to protect the environment and the health of your fellow mankind. Human health and the environment are endangered by inappropriate waste disposal. Recycling helps to reduce the consumption of raw materials.

ALPENHEAT IS NOT RESPONSIBLE FOR ANY DAMAGE TO THE PRODUCT OR INJURY TO THE USER CAUSED BY MISUSE OF THE PRODUCT.**MANUFACTURER'S LIMITED GUARANTEE:**

ALPENHEAT guarantees that this product is free from defects in material or workmanship. The guarantee period starts on the date on which the product was first purchased by an end customer. In the case of repairs or exchange, the guarantee period is neither extended nor does it begin anew. Should a defect occur during the guarantee period, the product has to be immediately returned to an authorized ALPENHEAT dealer, together with the corresponding dated purchase invoice. Within the guarantee period ALPENHEAT will at their sole decision repair or exchange the product.

EXCLUSION AND LIMITATIONS:

Batteries or battery packs are excluded from the guarantee. ALPENHEAT gives no guarantee for damages caused by accidents, negligence or improper use. Furthermore, textile wear, change of appearance, any product modification, damage to the product are also excluded from the guarantee. The manufacturer's limited guarantee does not affect statutory warranty rights. If the

DE defect is detected after manufacturer's limited guarantee has expired or it is not covered by this guarantee or there is no purchase invoice provided, ALPENHEAT reserves the right to determine and suggest which steps be taken (repair or exchange at the expense of the customer) at ALPENHEAT's sole discretion.

BG

CZ

Read instructions!

DK

Not in the household waste!

EE

Subject to change.

ES

FI

FR

GR

HR

HU

IT

LT

LV

NL

NO

PL

PT

RO

RS

RU

SE

SI

SK





ALPENHEAT Beheiztes Sitzkissen mit APP



Modell:
AJ7-APP FIRE CUSHION

INHALT:

- 1 Sitzkissen mit integriertem Heizelement (AJ7-APP)
- 1 Akku (BP3c)
- 1 USB-C Adapter (LG34c) und USB-C Ladekabel (LG35c)

GEBRAUCHSANWEISUNG

Sicherheitshinweise

Bewahren Sie das Produkt außerhalb der Reichweite von kleinen Kindern auf, da es verschluckbare Kleinteile enthält. Dieses Produkt sollte nicht von Personen verwendet werden, die nicht feststellen können, ob die Temperatur zu heiß oder zu kalt ist. Kleine Kinder reagieren empfindlicher auf Hitze und Kälte. Bestimmte Krankheiten, z.B. Diabetes kann eine beeinträchtigte Temperaturempfindlichkeit verursachen. Menschen mit Behinderungen oder gebrechliche Personen können möglicherweise nicht mitteilen, dass ihnen zu warm oder zu kalt ist. Daher ist das Produkt nicht geeignet für Kinder unter drei Jahren, gebrechliche oder hitzeunempfindliche Personen. Verwenden Sie unter Einnahme von Medikamenten und/oder Schmerztabletten keine Heizprodukte. Im Zweifelsfall oder bei Herz-Kreislauf-Problemen konsultieren Sie vor der Anwendung des Produkts Ihren Arzt. Verwenden Sie zum Laden der Akkus nur das mit dem Produkt gelieferte Original-Ladegerät. Es ist nur für die Verwendung trockenen Bereichen konzipiert und sollte keiner Feuchtigkeit ausgesetzt werden. Stecken Sie keine metallischen oder anderen Gegenstände in die Anschlussbuchsen oder den Stecker, da dies das Produkt beschädigen kann. Wenn Sie feststellen, dass die Anschlusskabel oder andere Teile beschädigt sind, verwenden Sie das Produkt nicht. Nehmen Sie keine Veränderungen am Produkt vor und verwenden Sie es nicht zweckentfremdet. Wenn Sie ein unangenehmes Gefühl, wie z. B. Kribbeln verspüren, kann dies ein Zeichen dafür sein, dass die Heizstufe zu hoch eingestellt ist. Sie sollte sofort reduziert oder das Sitzkissen sollte vom Akkupack getrennt werden. Produkte dürfen - wenn nicht benutzt - auf keinen Fall eingeschaltet nebeneinander oder zugedeckt gelagert werden, um einen Hitzestau zu vermeiden. Wenn das Produkt nicht verwendet wird, müssen die Akkupacks getrennt werden. Alpenheat-Produkte sind nicht untereinander oder mit Produkten anderer Hersteller kompatibel, verwenden Sie daher niemals Ladegeräte, Heizgeräte oder Akkupacks anderer Produkte.

WIE MAN DIE BATTERIEN AUFLÄDT UND SIE STARTET:

1. Laden Sie die Batterie vollständig auf, bevor Sie das Produkt verwenden.
Stecken Sie den Akku in das Ladegerät. Die grünen LEDs an den Batterie blinken

EN

DE

und zeigen damit an, dass die Batterien geladen werden. Ladestatus siehe Bild *Battery Status. Wenn der Akku vollständig aufgeladen ist, hören die grünen LEDs am Akku auf zu blinken und leuchten dauerhaft.

BG

2. Stecken Sie den Stecker des Sitzkissen in die Batterie. Eine rote LED beginnt zu blinken. Der Akku funktioniert nur, wenn dieser an das Sitzkissen angesteckt ist.

CZ

INBETRIEBNAHME MIT DER APP:

DK

3. Laden Sie die kostenlose APP herunter.

EE

4. Aktivieren Sie Bluetooth auf Ihrem Telefon und öffnen Sie dann die APP.

ES

5. In der APP: Sitzkissen in der Hauptproduktübersicht auswählen

ES

6. In der APP: Klicken Sie auf das blau blinkende Bluetooth-Verbindungssymbol auf des Sitzkissens

FI

7. Jetzt ist das Sitzkissen mit Ihrer APP verbunden

FR

8. Um die Temperatur zu ändern, klicken Sie in der APP auf die Schaltfläche „Heizstufe“ oder drücken Sie die Taste auf dem Akku.

FR

9. Klicken Sie in der APP auf die Ein-/Aus-Taste, um in den Standby-Modus zu wechseln. Die rote LED am Akku blinkt.

GR

So ändern Sie die Heizstufen (APP)

HR

- Drücken Sie NIEDRIG (blau) in der APP - die LEDs an den Batterien leuchten blau und das Sitzkissen arbeitet im Low-Modus.

HU

- Drücken Sie MITTEL (grün) in der APP - die LEDs an den Batterien leuchten grün und das Sitzkissen arbeitet im mittleren Modus.

IT

- Drücken Sie HIGH (gelb) in der APP - die LEDs an den Batterien leuchten gelb und das Sitzkissen im High-Modus.

LT

- Drücken Sie BOOST (rot) in der APP - die LEDs an den Batterien leuchten rot und das Sitzkissen arbeitet im Boost-Modus.

LV

-  Zum Ein- und Ausschalten drücken Sie den Knopf: GRÜN = EIN, GELB = AUS.

NL

MANUELLER BETRIEB:

NO

Stecken Sie den Sitzkissenstecker an den Akku, die rote LED blinkt. Drücken und halten Sie die Ein-/Aus-Taste am Akku, bis die grünen LEDs leuchten. Der Akku ist eingeschaltet und arbeitet im Medium-Modus.

PL

So ändern Sie die Heizstufe (Manueller Betrieb)

PT

- Drücken Sie die Ein-/Aus-Taste erneut, die Batterie-LEDs leuchten gelb und das Sitzkissen arbeitet im High-Modus.

RO

- Drücken Sie die Ein-/Aus-Taste erneut, die Akku-LEDs leuchten rot und das Sitzkissen arbeitet im Boost-Modus.

RS

- Drücken Sie die Ein-/Aus-Taste erneut, die Batterie-LEDs leuchten blau und das Sitzkissen arbeitet im niedrigsten Modus.

RU

- Drücken Sie die Ein-/Aus-Taste erneut, die Batterie-LEDs leuchten grün und das Sitzkissen arbeitet im mittleren Modus.

SE

- Halten Sie die Ein-/Aus-Taste am Akku gedrückt, bis die LEDs erlöschen. Die rote LED blinkt, der Akku schaltet sich aus und das Sitzkissen wird nicht erwärmt. Der Akku befindet sich im Standby-Modus.

SI

SK

Um den Akku komplett auszuschalten, trennen Sie das Kabel von dem Sitzkissen und vom Akku.

BATTERIELADEANZEIGE: *Battery status:

Wenn der Akku nicht mit dem Sitzkissen verbunden ist, drücken Sie kurz die Ein-/Aus-Taste am Akku, bis die LEDs aufleuchten. Die LEDs zeigen an, wie voll der Akku ist (*siehe Spalte rechts). Wenn der Akku mit dem Sitzkissen verbunden ist, zeigen Ihnen die je nach Heizstufe leuchtenden rot/orange/grünen/blauen LEDs, wie voll der Akku geladen ist.

ELEKTRISCHE PARAMETER: Li-Ion Akku:

Batteriespannung: 7,4 V /

Batteriekapazität 2200mAh / 16,28 Wh

LADEPARAMETER: Eingang: AC/100-240V
50-60Hz

Output: 5V/2,4A

Betriebsdauer: ca. 2 - 10 Stunden, abhängig von der gewählten Heizstufe.

Der Akku ist wasserabweisend und stoßsicher.

Nehmen Sie diesen auf keinen Fall auseinander.

GEBRAUCH:

Das beheizte Sitzkissen schafft eine behagliche und andauernde Wärme für Ihren Körper. Lassen Sie den Körper nicht erst kalt werden, denn zum Aufwärmen wird mehr Energie benötigt, als wenn Sie sie die ganze Zeit wärmen.

REGELN ZUR LI-IONEN UND LI-POLYMER AKKUPFLEGE:

- Der erste Ladevorgang ist entscheidend! Laden Sie den Akku vor dem ersten Gebrauch bitte vollständig auf.
- Wird der Akku unter seine Nennspannung entladen, kann dies zu Prozessen führen, die den Akku beschädigen oder zerstören. Die ALPENHEAT Akkus besitzen deshalb eine Elektronik, die das Gerät abschaltet, bevor es zu einer solchen Tiefentladung kommt.
- Auch häufiges Überladen kann den Akku dauerhaft schädigen. Deshalb beendet das Ladegerät automatisch den Ladevorgang, sobald der Akku vollgeladen ist. Dem Akku kann keinesfalls durch wiederholtes anschließen vermeintlich mehr Ladung zugeführt werden.
- Das Aufladen sollte in der Regel nur bei Zimmertemperatur (etwa 18°C bis 21°C) erfolgen. Vermeiden Sie es, einen kalten Akku aufzuladen, das schadet den Zellen. Speziell bei kalten Außentemperaturen im Winter den Akku immer erst bei Zimmertemperatur warm werden lassen, um ihn dann unter optimalen Bedingungen aufzuladen.

***Battery status:**

EN

DE

- Auch hohe Temperaturen schaden dem Akku. Lassen Sie den Akku an heißen Sonnentagen nie im Auto in der Sonne liegen.
- Li-Ion Akkus und Li-Polymer Akkus sollten am besten bei Raumtemperatur gelagert werden.
- Li-Ion-Akkus sollten über längere Zeit weder leer noch voll aufgeladen gelagert werden. Die in aufwendigen Versuchsreihen ermittelte optimale Lagerung liegt bei einer Kapazität von 30 % bis 50 % und bei niedrigen Temperaturen nicht aber unter 0 °C. Eine Aufbewahrung zwischen - 5 °C bis 45 °C (Li-Ionen) und 0 °C bis 40 °C (Li-Polymer) ist möglich, aber nicht optimal.
- Nachladen spätestens alle 6 Monate erforderlich!!
- Auch im unbenutzten Zustand verlieren Akkus Energie. Bei einem Li-Ion-Akku beträgt der Energieverlust ca. 3 % bis 5 % pro Monat.
- Alte und verbrauchte Akkus bitte immer umweltgerecht entsorgen

BG

CZ

DK

EE

ES

FI

REINIGUNG:

- Batterie entfernen.
- Nicht in der Waschmaschine oder von Hand waschen.
- Fleckenreinigung mit milder Seife, feuchtem Tuch oder weicher Bürste empfohlen. Nur abwischen, nicht als Ganzes in das Wasser tauchen.
- Keine Bleichmittel oder scharfen Reinigungsmittel verwenden.
- Das Kissen vor der Lagerung trocken lagern.
- Nicht im Trockner trocknen / nicht auswingen.
- Nicht bügeln.

FR

GR

HR

HU

IT

LT

LV

NL

NO

PL

PT

RO

RS

RU

ARTIKEL ENTSORGEN:

Dieser Artikel muss gemäß die geltenden Richtlinien für die Entsorgung von gebrauchten elektrischen und elektronischen Geräten entsorgt werden. Das Symbol auf dem Produkt oder seiner Verpackung weist darauf hin, dass dieses Produkt nicht als normaler Haushaltsabfall zu behandeln ist, sondern an einer Annahmestelle für das Recycling von elektrischen und elektronischen Geräten abgegeben werden muss. Dieser Artikel enthält einen Lithium-Ion (LI-Ion) Akku. Der Akku muss ebenso sachgerecht entsorgt werden. Zu diesem Zweck stehen in den entsprechenden Sammelstellen Behälter zur Akku-Entsorgung bereit. Der Akku darf nicht auseinander genommen, ins Feuer geworfen oder kurzgeschlossen werden. Durch ihren Beitrag zur korrekten Entsorgung dieses Produkts inkl. Akku schützen sie die Umwelt und die Gesundheit ihrer Mitmenschen. Umwelt und Gesundheit werden durch falsches Entsorgen gefährdet. Materialrecycling hilft den Verbrauch von Rohstoffen zu verringern.

ALPENHEAT IST FÜR DIE BESCHÄDIGUNG DES PRODUKTES ODER DIE VERLETZUNG DES BENUTZERS DURCH FALSCHER ANWENDUNG NICHT VERANTWORTLICH.

SE

SI

SK

BESCHRÄNKTE HERSTELLERGARANTIE:

ALPENHEAT garantiert, dass dieses Produkt frei von Material- oder Herstellungsfehlern ist. Die Garantiefrist beginnt mit dem Datum, an dem das Produkt erstmals von einem Endkunden erworben wird. Sie wird durch erfolgte

Reparaturmaßnahmen oder Austausch weder verlängert noch beginnt sie von neuem. Sollte während der Garantiezeit ein Mangel an Ihrem Produkt auftreten, ist das Produkt unverzüglich an einen autorisierten ALPENHEAT-Händler zurückzugeben und ein entsprechender datierter Kaufbeleg vorzuweisen. Innerhalb der Garantieperiode entscheidet ALPENHEAT ob der Mangel durch Reparatur oder Austausch des Geräts behoben wird.

AUSSCHLUSS UND BESCHRÄNKUNGEN:

ALPENHEAT gewährt keine Garantie für Schäden infolge von Unfällen, Fahrlässigkeit und unsachgemäßer Verwendung. Außerdem sind von der Garantie ausgeschlossen: Verschleißteile, Textilabnutzung, Veränderung von Aussehen, unsachgemäß vorgenommene Produktmodifikationen, Beschädigungen am Produkt. Die Herstellergarantie lässt Ihre gesetzlichen Gewährleistungsansprüche unberührt. Ist der Fehler nicht durch diese Garantiebedingungen gedeckt, behält ALPENHEAT sich vor, den fehlerhaften Teil nach eigenem Ermessen zu reparieren oder zu ersetzen.

Anweisungen lesen!
Nicht in den Hausmüll!
Änderungen vorbehalten.

